

# INSTRUCTION

## **QUICK REFERENCE TIMER INSTRUCTIONS**

Press **RESET** button to reset the system (this erases all settings).

### **1. Set time, day, and date.**

- Turn rotary selector to "**SET TIME/DATE.**"
- To set time: Press "+" or "-" key to advance clock to correct time of day. Press **ENTER**. (Blinking cursor moves to year.)
- To set year: Press "+" or "-" key to change year. Press **ENTER**. (Blinking cursor moves to month.)
- To set month: Press "+" or "-" key to change month. Press **ENTER**.  
January is 1, February is 2, etc. (Blinking cursor moves to date.)
- To set date: Press "+" or "-" key to change date. Press **ENTER**. Current time appears on the display.
- To review settings, press **NEXT**.
- To make changes, press **NEXT** to desired mode and repeat steps.

### **2. Set cycle start times for A (14-day calendar) and/or B Program (interval watering).**

- Turn rotary selector to [A] or [B] **SET CYCLE START TIMES**. The cursor will blink at start time 1 on the display.
- Press "+" or "-" key to advance to desired cycle start time. Press **ENTER**.
- If more than one cycle start time is required, press **NEXT** and repeat steps for up to four start times per day for A or B Programs.
- To review cycle start times, press **NEXT**.  
To clear cycle start times, press **CLEAR**.

### **3. Set watering days for A Program (14-day calendar).**

- Turn rotary selector to [A] **SET WATERING DAYS**.  
Cursor will blink above the current day of the week on the display for week 1 or week 2.
- To set a watering day, press **ENTER**.  
(Flag appears under cursor indicating active watering days.)
- To skip a watering day, press **NEXT**.
- To clear a watering day, press **CLEAR**.

### **4. Set watering interval for B Program. (Note: Step 2 to enter cycle start time[s] for B Program).**

- Turn rotary selector to [B] **SET WATERING INTERVAL**. The cursor will blink at "INTERVAL" on the display.
- To enter an interval, press "+" or "-" key  
(Example: an interval of 5 will water today and then every 5th day.)
- To enter watering on odd or even days, press **NEXT** until cursor is blinking to the right of odd or even. Press **ENTER**.
- To clear an interval and odd or even days, press **CLEAR**.