

Unlike a traditional hose washer, the HydroSeal™ stops leaks keeping your arms and legs dry!

STEP 1: Remove traditional washer

STEP 2: Insert HydroSeal™ Washer as shown below

STEP 3: Connect hose

Note: HydroSeal™ washers are designed to work with sprinklers and nozzles that attach to the hose end (male end) of the garden hose. HydroSeal™ may not work with all hoses. The black washers are included for replacement at the faucet end of the hose.

For cold water outdoor irrigation use only.
Not for use on appliances.



hydroseal.orbitonline.com